

The following instructions explain how to install CX0082-IN08 Insulator Sleeve on WR-VGCO81-BRD Low Inductance wire.

Installation requires the following tools:

- Tape
- Wire Cutter
- Jacket stripping tool



Installing CX0082-IN08 Insulator Sleeve on WR-VGCO81-BRD:

1) Measure and strip the outer jacket according to RRU requirement.



2) Twist the outer copper strands together.



3) Cut the non-insulated copper wire according to RRU requirement.

4) Strip the jacket of the red insulated conductor as needed.



5) Insert the Low Inductance wire into the insulator sleeves.



Consult RRU installation instructions for additional information..