Installation Instruction SLWK112-C03



Rosenberger Jumper Boot (RJB) for weatherproofing of 7-16 DIN Male Connector onto Female Bulkhead Connector. The RJB is preassembled on the jumper at the factory and is not to be removedand reused on another jumper.


Steps when connecting to standard 7-16 DIN female bulkhead



RJB (1) comes preassembled on the jumper cable. It is designed to seal to the smooth neck of the standard 7-16 DIN female bulkhead with an OD of 25–30mm.



Straighten the cable ≥ 4 inches (100mm) from where it exits the 7-16 DIN male connector. Ensure cable and connector are clean. Connect the jumper cable to the device and properly torque the connection.



Slide the RJB until it stops across the connection. Final position according to the inset photo above. RJB lands on the smooth diameter beyond the threads of the female connector, providing IP68 sealing. Do not squeeze the circumference of the RJB after installation as this can cause future water ingress.


Draft Date Approved Date M. Wimmer 13.08.2015 M. Wimmer 21.08.2015

Corporate Headquarters Rosenberger Hochfrequenztechnik GmbH & Co. KG P.O. Box 1260 D-84526 Tittmoning Germany Tel. +49 8684 18-0

Additional steps when fully threaded (22mm minimum thread length) 7-16 DIN female bulkhead used



Install the Rosenberger Thread Adapter (RTA), p/n SLWK112-C03/51 (sold separately) in the correct position per the photo above (9mm from front connector interface). There must be adequate thread length to provide this 9mm and space for the RTA. The RTA is required to achieve IP68 sealing with the RJB to the fully threaded version of the 7-16 DIN bulkhead. Please proceed to step 2.



Turn the RTA counterclockwise until it comes in contact with the DIN connector nut. Verify the RTA is squarely aligned with the connector nut and seated into the bulkhead threads. Please proceed to step 3A.



In this installation, the RJB lands on the RTA as shown in the inset photo above, providing IP68 sealing. The RJB must be installed squarely to the RTA with no more than 1 of the 3 RTA grooves exposed. The 2 RTA tabs will be exposed, providing visual proof of proper installation. Do not squeeze the circumference of the RJB after installation as this can cause future water ingress.

Rev.	Engineering change number	Name	Date
a00	15-s265	S. Krautenb.	21.08.2015
Poor	phorgor Site Solutions II C		


Rosenberger Site Solutions, LLC P.O. Box 4268, Lake Charles, LA 70606 Ph.337.598.5250 Fax: 337.598.5290 rlss@rlss.us www.RosenbergerOnline.us

Page 1 of 2

Installation Instruction SLWK111-C03




Rosenberger Jumper Boot (RJB) for weatherproofing of 4.3-10 DIN Male Connector onto Female Bulkhead Connector. The RJB is preassembled on the jumper at the factory and is not to be removed and reused on another jumper.




Step 1 Ø17 - 20 mm

RJB (1) comes preassembled on the jumper cable. It is designed to seal to the smooth neck of the standard 4.3-10 DIN female bulkhead with an OD of 17-20mm.



Straighten the cable ≥ 4 inches (100mm) from where it exits the 4.3-10 DIN male connector. Ensure cable and connector are clean. Connect the jumper cable to the device and properly torque the connection.



Slide the RJB until it stops across the connection. Final position according to the inset photo above. RJB lands on the smooth diameter beyond the threads of the female connector, providing IP68 sealing. Do not squeeze the circumference of the RJB after installation as this can cause future water ingress.

Draft	Date	Approved	Date	
M. Wimmer	13.08.2015	M. Wimmer	21.08.2015	

Rev. Engineering change number Name Date a00 S. Krautenb. 21.08.2015 15-s265

Page

2 of 2

Corporate Headquarters Rosenberger Hochfrequenztechnik GmbH & Co. KG P.O. Box 1260 D-84526 Tittmoning Germany Tel. +49 8684 18-0

Rosenberger Site Solutions, LLC P.O. Box 4268, Lake Charles, LA 70606 Ph.337.598.5250 Fax: 337.598.5290 rlss@rlss.us www.RosenbergerOnline.us